555 E Queen Creek Rd Bldg A Chandler, AZ 85286 WWW.DV80FFROAD.COM

INSTALLATION MANUAL

CENTER CONSOLE MOLLE

2024+ TOYOTA TACOMA CCT1-02



TOOLS REQUIRED

- #3 Allen
- M5 Nutsert Tool
- Marker
- Drill
- -1/4" Drill Bit

SKILL LEVEL

- Novice/Intermediate
- -1 (you) to 2 persons

Little skill level required, you can easily install it by yourself however, additional help will be useful

TIME REQUIRED

-1.5 Hours

Time to install this should only take about an hour and a half.

WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit — Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product. Customer Service: 855-680-9595

DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

• Always wear eye protection when operating power tools

Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information

- 1. Name of purchase location
- 2. Bar Code on side of box
- 3. Date above bar code
- 4. Date inside box cover





INSTALLATION MANUAL

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from. Extra hardware may be included with the product.

HARDWARE INCLUDED

(12) M5x16mm Bolts

(12) M5 Washers

(14) M5 Nutserts



STEP 1 | Place the bracket against the center console of the vehicle.

Focus on the top edge of the bracket with the trim line of the vehicle. Using a marker, mark the mounting holes of the side brackets.



STEP 2 Use a 1/4" drill bit to drill the marked holes. Only cut through the plastic of the center console.







INSTALLATION MANUAL

 $\begin{array}{c|c} \text{STEP 3} & \text{Use a M5 nurtsert tool to} \\ \text{install the nutsert.} \end{array}$





STEP 4 | Align the driver side mount with the holes secure molle using the provided M5 hardware.





INSTALLATION MANUAL

STEP 5 | Repeat steps 1-4 with the passenger side molle. The top of the molle will align with the center console trim and grab handle.



STEP 6 | Double check fitment and all hardware is secure.



STEP 7 | Congratulations, you are finished with the install of the Tacoma Center Console Molle.



