

FRONT DOOR MOLLE POCKETS

2011-2018 JEEP JK WRANGLER

MPJK-05



TOOLS REQUIRED

- T-25 Torque head socket
- Scissors/ Cutting Tool
- Safety Glasses

SKILL LEVEL

- Novice/Intermediate
- 1 (you) to 2 persons

Little skill level required, you can easily install it by yourself however, additional help will be useful

TIME REQUIRED

- .5 Hours

Time to install this should only take about half an hour

WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit – Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.
Customer Service: 855-680-9595

DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

- Always wear eye protection when operating power tools

Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover



INSTALLATION MANUAL

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from. Extra hardware may be included with the product.

HARDWARE INCLUDED

- (2) M5X30 Hex Screws
- (2) M5 Washers
- (2) Nylon Spacer



STEP 1 | Begin by using scissors or cutting tool to remove the factory door pocket netting and elastic band.



STEP 2 | Use a T-25 socket to remove screw at bottom of door panel.



INSTALLATION MANUAL

STEP 4 | Push the pocket into place by placing the tabs on the pocket between the pocket molding and the door panel.



STEP 5 | Secure the pocket by inserting the provided hold down bracket into the bottom hole.

Note: Press firmly to ensure bottom tab, is seated completely or hold down bracket hardware will not fit properly.



STEP 3 | Place the spacer between the door panel and the L bracket.



INSTALLATION MANUAL

STEP 6 | Use the provided M5 screw to secure the L bracket.



STEP 7 | Repeat on other side and double check all hardware is secure.

Congratulations installation of the DV8 JK Front Molle Pockets is now complete.

