

SHOCK SKIDS

24+ TOYOTA TACOMA

SPTT1-06



TOOLS REQUIRED

- 17mm, 19mm Socket
- Torque Wrench

SKILL LEVEL

- Novice/Intermediate
- 1 (you) to 2 persons

Little skill level required, you can easily install it by yourself however, additional help will be useful

TIME REQUIRED

- 1.5 Hours

Time to install this should only take about an hour and a half.

WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit – Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.
Customer Service: 855-680-9595

DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

- Always wear eye protection when operating power tools

Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover



INSTALLATION MANUAL

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from. Extra hardware may be included with the product.

HARDWARE INCLUDED



- Factory Hardware



STEP 1 | Use a 17mm socket to remove the shock mount factory bolt circled in the picture.

Use a 19mm socket to loosen the link mount bolt (see arrow). Do not remove nut.

Note: Factory shock mount bolt will be reused.



INSTALLATION MANUAL

STEP 2 | Slide the skid plate under the loose link mount bolt and adjust into place.

You can use a mallet to





STEP 3 | Using the factory shock mount bolt secure the skid plate.




STEP 4 | Secure the shock mount bolt in the first picture using a 17mm socket. Torque to 65 ft-lbs.

Secure the link mount bolt in the second picture using a 19mm socket. Torque to 97 ft-lbs.



INSTALLATION MANUAL



STEP 5 | Double check fitment and all hardware is secure.

Congratulations. You have completed your install of the DV8 Shock Skids.

