

## 4-DR ROCK SLIDERS

18+ JL WRANGLER

SRJL-07



### TOOLS REQUIRED

- 10" Ratchet Extension
- 10, 13, 16, 18mm Socket

### SKILL LEVEL

- Novice/Intermediate
- 2 persons

Little skill level required, however, additional help is required for removal and installation of sliders.

### TIME REQUIRED

- 1 Hour

Time to install this should only take about an hour.

## WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit – Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.  
Customer Service: 855-680-9595

*DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.*

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

- Always wear eye protection when operating power tools

*Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information*

1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover



# INSTALLATION MANUAL

**STEP 1** | If you have factory steps or sliders, they will need to be removed prior to install.

Use a 10mm socket to remove the factory nuts securing the slider to the body/pinch weld.

Then, while a friend supports the slider, remove the remaining factory hardware using a 13mm socket.

Remove the slider and set it off to the side. Repeat steps for opposite side of the vehicle.

*Note: Assistance is recommended to prevent injury and damage to the product or vehicle.*



# INSTALLATION MANUAL

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from. Extra hardware may be included with the product.



**STEP 2** | Use an 18mm socket to remove the factory body mount bolt from the forward body mount located closest to the front tire.



# INSTALLATION MANUAL

**STEP 3** | Use a 16mm socket to remove the nuts from the factory studs located in the two rear body mounts.



# INSTALLATION MANUAL

**STEP 4** | With help from a friend, place the sliders on the vehicle.

Start by lifting the front mount into place, and then slide the middle and rear mounts into place. Use a 16mm and 18mm socket with a 10" extension to loosely secure the sliders to the vehicle.

*Note: Assistance is recommended to prevent injury and damage to the product or vehicle.*



**STEP 5** | When all hardware is loosely installed, finish securing all factory hardware using a 16mm and 18mm socket with a 10" extension.

Double check fitment and all hardware is secure.

Repeat steps on opposite side of the vehicle.



# INSTALLATION MANUAL

**STEP 6** | Congrats! You are finished with the install of the 18+ JL Wrangler Rock Sliders!

