


## JK TIRE CARRIER REINFORCEMENT MOLLE PANEL

07-18 JEEP WRANGLER (JK)

TCJK-04



### TOOLS REQUIRED

- #4, #6 Allen Tool
- 13mm sockets
- Trim Tool
- Safety Glasses

### SKILL LEVEL

- Novice
  - 1 (you) to 2 persons
- Little skill level required, you can easily install it by yourself however, additional help will be useful

### TIME REQUIRED

- 1.5 Hours
- Time to install this should only take about one and half hours.

## WARNINGS/CAUTIONS BEFORE STARTING INSTALLATION

Before you install this kit — Read and understand all instructions, warnings, cautions, and notes contained in this installation instruction guide. Consult your vehicle owner's manual for proper disconnection of electrical and lifting of vehicle if required for installation of this product.

This install may require some technical skills and knowledge of basic mechanical work. If you do not feel that you are capable of performing this install please take this product to a trained professional.

After reading this guide please contact us with any questions or concerns before installing product.  
Customer Service: 855-680-9595

*DV8 Offroad is not responsible for any bodily injury or harm to you or your vehicle as a result of an improper install.*

Proper installation of this kit required knowledge of the factory recommended procedures for removal and installation of original equipment components. We recommend that the factory shop manual and any special tools needed to service your vehicle be on hand during the installation. Installation of this kit without proper knowledge of the factory recommended procedures may affect the performance of these components and the safety of the vehicle

- Always wear eye protection when operating power tools

*Inspect all contents of this package to make sure product is not damaged and all installation hardware has been included. If parts are missing from kit, please be prepared to provide the following information*


1. Name of purchase location
2. Bar Code on side of box
3. Date above bar code
4. Date inside box cover

# INSTALLATION MANUAL

Begin by unpacking all items and inspecting for missing pieces or damage. If you have any concerns, please contact the company the product was purchased from. Extra hardware may be included with the product.

## HARDWARE INCLUDED

- (4) M10x25 Allen head bolts
- (4) M8x30 Hex head bolts
- (4) M10 Lock washers
- (4) M8 Flat washers
- (4) M8 Lock washers
- (4) M8 Flat washers



**STEP 1** | Begin by removing the spare tire off the JK. Lug nut size can vary depending on OE and aftermarket lug nuts.



# INSTALLATION **MANUAL**

---

**STEP 2** | Using a trim tool, remove the two caps over the factory hinges.

These caps will not be reused.



**STEP 3** | Keep the door closed during this step.

Using a 13mm socket, remove the 2 hinge bolts front the top hinge only.







**STEP 4** | Using the M8x30 hex head bolts, install the top mounting bracket to the top hinge until secure using a 13mm socket.



## INSTALLATION MANUAL

---

**STEP 5** | Once the top is installed, repeat the steps for the bottom hinge.





## INSTALLATION MANUAL

---

**STEP 6 |** Using the 13mm socket, remove the factory tire carrier. You can let it dangle with the wires carefully for this install.



**STEP 7 |** Clean up any dirt or debris.



**STEP 8 |** Unpeel the foam provided and place it onto the backside of the carrier malle.

Note the direction of the foam and panel to prevent placing it on the wrong side.





**STEP 9 |** Hold the panel up to the hinges installed earlier and align the nutserts on the hinges to the slots on the panel.

Line up the notches in the panel and the hinges so they align. Mounting using a #6 allen head and the M10 allen head bolts.

Keep hardware loose.





## INSTALLATION MANUAL

---

**STEP 10** | Hold up the factory tire carrier and using the factory hardware and 13mm socket, install the carrier over the reinforcement plate.



**STEP 11** | Tighten the hinge mounting hardware using a #5 allen head.





## INSTALLATION MANUAL

---

**STEP 12** | Reinstall the tire onto the tire carrier and tighten lug nuts to factory recommend torque for the spare mount.



**STEP 13** | Double check all hardware is secure.

Congratulations, you are done with the install of the DV8 JK Reinforcement Molle Panel.

